



## HOW TO INSTALL GLASS IN YOUR WALL MOUNTED FIXTURE

Using Rubber Gloves and two hands:

**1. Install the first side panel** (either right or left)

Slide one glass side pane in the front door and between the candle holder, tilting away from the side where the glass will seat. Once all the way into the lantern, tilt the top towards the side where it will be installed and carefully slide the top of glass up into the top slot of the window frame. Once the glass is all the way up into the slot, the bottom can be shifted into the window and the piece of glass can gently slide down into the bottom slot.

**2. Install rear mirror first (if applicable)**

For Partial mirror where applicable, place the mirror between the two copper side tabs and gently bend the side tabs until the mirror is snug.

For Full width mirrors, slide the mirror holder up so the bottom is above the candle font, slide the mirror glass in from the side tilted to towards the back. Slide the mirror up into the top channel of the mirror holder. Tilt back and allow the bottom to slip into the lower slot. Shift mirror towards side glass panel first installed.

**3. Install pewter reflector (if applicable)**

Hook the tab on the back of the pewter reflector into the tab holder in the rear of the lantern behind the bulb.

**4. Install the side panel** (either right or left)

Repeat Step 1 for the second side panel. Once installed, center the mirror in the back of the lantern.

**5. Install the door glass panel**

In the same manner as side panels, slide the door pane up into the top slot, allowing it to slip down into the bottom slot.

**6. Install the glass chimney**

Install the light bulb. Once the fixture is working, slide the top of the glass chimney up into the top of the lantern, lowering it down over the bulb and gently into the shade holder.